













RH1062-GL ASSEMBLY INSTRUCTION

	 <p>①×1 1800×900×46</p>	 <p>②×1 800×300×25</p>	 <p>③×1 632×180×655</p>	 <p>④×1 358×30×30</p>	 <p>⑤×1 228×30×30</p>
	 <p>⑥×1 835×485×26</p>	 <p>⑦×12 M8×30</p>	 <p>⑧×12 φ22×φ8.2</p>	 <p>⑨×4 M8×45</p>	 <p>⑩×1 5#</p>

